

Tips for assembly on the Aston Counter QT-805

leave the back panels at last until the front panel are connected with the 2 cabinets, then cams are locked in the 2 back panels, otherwise assembler can't access the connection screws between the front panel and cabinets.

