



Plantation Bar Leaner 1800 x 600

Assembly Instructions

Plantation Bar Leaner 1800 x 600

Assembly Instructions



STEP 1: Assemble spreader bar to legs.



STEP 2: Attached spigot to spreader bar.



STEP 3: Attached rails to spiggots.



STEP 4: Attach worktop to frame.