












# ASSEMBLY INSTRUCTIONS

## CDK96



pin	6x35
	1
	10PCS
CAM	
	2
	10PCS
Cam Cover	
	3
	10PCS
CAM	
	4
	4PCS
Screw	6x50
	5
	4PCS
	













# ASSEMBLY INSTRUCTIONS

## CDK189

## CDK1875




pin	6x35
	1
	10PCS
CAM	
	2
	10PCS
Cam Cover	
	3
	10PCS
CAM	
	4
	4PCS
Screw	6x50
	5
	4PCS
	








# ASSEMBLY INSTRUCTIONS

## CDK1575

## CDK126



pin	6x35
	1 10PCS
CAM	
	2 10PCS
Cam Cover	
	3 10PCS
CAM	
	4 4PCS
Screw	6x A50
	5 4PCS
