









ASSEMBLY INSTRUCTIONS


CCW96



1






2










ASSEMBLY INSTRUCTIONS

CWR3





pin	6×35
	1
	7PCS
CAM	
	2
	7PCS
Cam Cover	
	3
	7PCS
CONNECTOR 200×60×2	
	4
	1PCS
Screw	6×12
	5
	8PCS
	










ASSEMBLY INSTRUCTIONS

CWR6




pin	6×35
	1
	8PCS
CAM	
	2
	8PCS
Cam Cover	
	3
	8PCS
CONNECTOR	200×60×2
	4
	1PCS
Screw	6×12
	5
	8PCS
	




ASSEMBLY INSTRUCTIONS

CWR12

CWR9



pin	6×35
	1 8PCS
CAM	
	2 8PCS
Cam Cover	
	3 8PCS
CONNECTOR	200×60×2
	4 1PCS
Screw	6×12
	5 8PCS
	

